






(MX-190CD)



Product name Rcom MARU DELUXE MAX 190

Manufacturer AUTOELEX
Brand MARU DELUXE
Model MX-190 CD

Origin MADE IN KOREA





Credit evaluation in the global incubators market

By FACT. MR, research agency in Ireland



ReomMARU DELUXEmax 190 HIGH-PERFORMANCE DIGITAL INCUBATOR ARTIFICIAL INTELLIGENCE It has been designed to analyze airflow from computer simulation in order to keep optimal environment inside of incubator and applied high digital technology to control automatic hatching system.

RCOM

THE TECHNOLOGY

RCOMMPRUMPX

DIGITAL INCUBATOR

WATER EMPTY

Door sensing fucntion

Internal Micro switch which can

present temporary temperature rise from door opening and closing

> Power Connecting (the rear) For connecting power cord.

Nipple for water hose

Temp, Humi. sensor/

Tray (Cradle Type)

Door detecting micro switch

190, 380 : 3Layers(1Role) 1000 : 4Layers(2Roles)

Universal Egg Basket

(Sold Separately)

Sold Separately

Air Controlling Lever

affecting insulation. When eggs start hatching, open air controlling lever either fully or half-open. If you set high temperature, condensation will occur the near Air Vent and may causes licking water from the

incubator and it is not a technical problem.

close

HUMDITY

DIGITAL INCUBATOR

Turning the jog dial 360° will move the cradle and pressing it will stop

 Cradle Type

WATER EMPTY

(10)

1/2 open

Outer fresh air can be flowed into incubator inside without

wide open

Insulation Board

Jog Dial

TEMPERATURE

TURNING ON

LED indoor light LED indoor light which can

Smart jog-dial system

Innovative design raised

durability by applying easy operation jog-dial method

Air inlet vent

Air Vent (Front)

Control Panel/

Display Window

LED Room Light

Dual structured

Hatchery room Temporary space for hatchery

Rubber foot, Door Guide

1/4 open

insulated window

Door

refer to control panel function description CREATION OF MOST VALUABLE LIFE BIRTH!

SOLD SEPARATELY

> WORLD CLASS PRODUCT OF KOREA

Love of Life begins with Rcom.

We are the R-Com, loving life and nature,

going to do whatever we want and believe."

The Enterprise Loves the Nature, Human, and Life.

with their positive thinking and warmhearted.

Autoelex Co., Ltd., was established in 1991 with our motto "We are certainly

We' ve expanded our market about 30 ather countries for our R-Com brooders and continued trying to be known in the world as the best brand, based on our high technology and innovative thinking. And we;ve finally became one of the best brooder manufacturing company in the world/

We, RCOM highly expecting our customers' children have a successful life

BRAND INFO

PRODUCT DETAILS

Superb high density foam board Advanced concept New egg turning device PTC heater humidity unit A thick coated sheet for warmth for stable electricity interception from external electric shock efficiency by applying PTC heater and maintenance of safe humidification effect without overheating reinforcement and embossing surface treatment to present pollution [IDENTIFICATION OF PARTS]

Air Vent (Front)

mannan manan m

MINIMAN MILITA

Rcom (7) DIAL FUNCTION O TEMPER ATURE

н

LO C/F

S.on / S.off

TURNING ON

Names and components of each part

Pumping System Operation Lamp: Light on when working

Horizontal eggs turning button (3 seconds) * Cradle Type /

Tunction Table: Function can be selected in order by using the jog dial

Forced egg turning button (3 seconds) * Slide Type

Water Supplement Lamp : Blink with water shortage

- Function setting mode will appear when pressed for 3 seconds

® Outage Notification: Blinks during power outages. (Release button: press the jog dial once)

- Temp. and humi. can be checked when pressed for 1 second

Heater Operation Lamp: Light on when working

Temp. Display: Current Temperature Display ③ Humidity Display : Current Humidity Display

⑤ Jog Dial: Press and turn left and right

⑥ Room Light Button (1 second) /

HIGH ALARM

LOWALARM

[FUNCTIONS OF OPERATION]

Cradle type tray

[INTERIOR]

Cradle egg

turning device

Duplicated view

window

Egg Basket

with ABS divider

(sold separatly)

Name

CT Series model No.

- Digital Humi. & Water hose connector Slide type Air-vent Temp. sensor

Foam board

Egg Basket with cover

(sold separatly)

- [Useful Function] * Built in LED dome-light for ease of viewing when door is open Degree C / degree F interchangeable Separate humidifier not required due to built-in humidifier unit within the device * Warning & display function of abnormal temperature caused by ambient temperature fluctuation * Incubation data memory and alarm function in case of blackout * Equipped with water nipple in front for efficient water supply

* Equipped with removable upper cover for convenience of cleaning or maintenance after incubation * Automatic horizontal positioning stop function and manual location adjustment function for effortless tray removal Adjustable universal egg trays suitable for a variety of egg sizes (sold separately) [Sold Separately] * Universal Egg Basket and ABS Divider

- QUALITY CERTIFICATION
 - (E C 세계일류상품

Capacities [Chick egg size] 168 336 840 Cradle Egg turning method Cradle Cradle 0, 90° (±5°) 0, 90° (±5°) 0, 90° (±5°) Egg turning angle(°) Egg turning Interval[min] 0,60,120,180 0,60,120,180 0,60,120,180 Humidification device Option Egg basket / ABS divider Egg basket / ABS divider Egg basket / ABS divider The number of trays 3 floors×1row 3 floors×1 row 4 floors×2row $Size[W \times L \times H(mm)]$ 425x473x765 425x790x765 845x790x890 temperature:20~42°C (68~107,6°F) temperature: 20~42°C (68~107.6°F) temperature: 20~42°C (68~107,6°F) Functional ranger humidity:20~70% humidity: 20~70% humidity: 20~70% Weight[Kg] 24 33 74 Maximum electric power[W] 440 440 440 70 Average electric power[W] 70 70 [Main Function]

* Innovative PTC Heating Type humidifier eliminates bacteria from humidity reservoir (Stainless humidity unit) Increased temperature stability and energy efficiency due to high-density insulated body developed by Rcom Built-in 'open door' micro-switch detection (Improvement on temporary temperature rise when opening the door)

* Built-in water level sensing switch automatically detect the water level inside the humidifier and alarm water refill is required * Precise temperature and humidity sensor produced by Sensirion, Swiss (ver. 3rd Generation of Sensirion, Swiss) Dependable temperature by Rcom optimum air flow technology

Convenient jog dial operation for optimized user interface

* Integrated simple control panel (superior maintenance)

* FND display for easy recognition of incubation state

Transparent double insulated viewing window

Sliding vent to in the chamber

* Automatic temperature & humidity control and set function

* Automatic egg turning & turning interval set function (1h, 2h, 3h)

Artificial intelligence electronic control system by Rcom technology

- Use distilled water Use with tap water Above picture shows after test on brooder and every other incubators show same. After hatching, please put chicks in to Brooder immediately. If you leave new born chicks in incubator, the incubator can be contaminated and affect adversely

it can cause failure of machine, in this case, we do not provide free of charge warranty service but charge it.

- - International Organization for
 - KIPO **Standardization**

Tube clamp

POM

reinforcement hinge

Main controller

Air booster

To minimize temp variation inside

the incubation Airflow simulation

200°C heat-treated electrostatic

power coating for enhanced

corrosion-resistance and durability

DELUXE MAX 380

MX-380CD

PTC Humidifi cation unit

[RCOM MARU DELUXE Function Comparison] Rcom MARU Rcom MARU

DELUXE MAX 190

MX-190CD

* CAUTION *

If you want to use other one, please contact to purchase shop.

- for nest hatching.

- We recommend use distilled water not forming scale in the water tank. After hatching, please clean it up, other wise scale can be formed in the water tank and

- Rcom MARU DELUXE MAX 1000 MX-1000CD

AUTHORISED DISTRIBUTOR



● OFFICE : 1066, Civil Lines, Station Road

Jhansi, U.P-284001, INDIA

● Contact :+91-9559777053

● E-MAIL : thepetsnation@gmail.com

info@petsnation.in

Website : www.petsnation.in

CLICK ON DISTRIBUTOR TO CONTACT ON WHATSAPP